COOKTOP, BURNER AND GRATE PARTS

For Models: KGCT365EBL0, KGCT365EWH0, KGCT365EAL0
(Black) (White) (Almond)

KitchenAid®

36" GAS
GLASS SURFACE COOKTOP
Non−Reignition



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP, BURNER AND GRATE PARTS

For Models: KGCT365EBL0, KGCT365EWH0, KGCT365EAL0
(Black) (White) (Almond)

Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1		Cooktop, Glass
	3190808	White
	3190807	Black
	3190809	Almond
2		Grommet, Glass Cooktop (4)
	3180081	White
	3180079	Black
	3180080	Almond
3		Bezel, Cooktop (Large)
	4454597	White
	4454595	Black
	4454596	Almond
7	3189021	Speed Nut (12)
8		Bezel, Cooktop (Small)
	4454600	White
	4454598	Black
	4454599	Almond
12	3186678	Pad, Grate (Includes 5 pads)
13		Grate, Large (RF & LR) (Includes No. 12)
	3186677	White
	3186675	Black
	3186676	Almond
14		Grate, Small (LF & RR) (Includes No. 12)
	3186674	White Model
	3186672	Black Model
	3186673	Almond Model
15		Cap, Rapid Burner Large (2)
	3185794	White
	3185793	Black
	3185792	Almond
16		Cap, Semi Rapid Small (2)
	3185797	White
	3185796	Black
	3185795	Almond
17		Knob, Control (4)
	3182568	White
	3182567	Black
	3182569	Almond
18	3188799	Burner, Small (2)
19	3188798	Burner, Large (2)

BURNER BOX, GAS VALVES, AND SWITCHES

For Models: KGCT365EBL0, KGCT365EWH0, KGCT365EAL0
(Black) (White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BURNER BOX, GAS VALVES, AND SWITCHES

For Models: KGCT365EBL0, KGCT365EWH0, KGCT365EAL0
(Black) (White) (Almond)

Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1	3191124	Backer Plate
2	3189302	Pipe, Manifold
	3177991	Screw (4)
3	3185828	Valve, Gas Burner (LF & RR)
4	3188425	Seal, Shaft
5	3185827	Valve, Gas Burner (RF & LR)
8	3185829	Bolt, Gas Valve
10	4454647	Bracket, Burner (4)
	3148443	Screw (8)
	4454663	Screw (4)
11	3191098	Bracket, Burner Box (8)
	3148443	Screw (16)
	3148442	Screw (8)
12	3190779	Switch, Gas Burner
14	4454624	Tubing, Large Gas Burner (RF)
15	4454625	Tubing, Small Gas Burner (LF)
16	4454626	Tubing, Large Gas Gas Burner (RR)
17	4454627	Tubing, Small Gas Burner (LR)
21	3177120	Regulator, Pressure
22	3191133	Burner Box
	3148443	Screw (4)
27	3186493	Module Spark
	3148443	Screw

LITERATURE PARTS

LIT3190961	Installation Instructions
LIT3190960	Use & Care Guide
LIT3190954	Wiring Diagram

SEALED GAS BURNER ASSEMBLY

For Models: KGCT365EBL0, KGCT365EWH0, KGCT365EAL0
(Black) (White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1		Sealed Gas Burner Assembly
	3188798	Large Burner
	3188799	Small Burner
2	3185805	Nut
4	3185804	Electrode
5		Orifice, Burner
	3185947	Small Burner
	3185948	Large Burner

PARTS NOT ILLUSTRATED

Illus. No.	Part No.	DESCRIPTION

Following Parts Not Illustrated

3188867	Cord, Power
3148443	Ground Screw
4173634	Bushing
3183401	Bracket
4167077	Tinnerman Nut
3179557	Screw (2)

Miscellaneous

3188310	Hardware, Mounting
4173627	Conversion Kit Natural Gas To L.P.
3179164	Tape, Foam

WIRING HARNESS PARTS

3191088	Harness, Switch
3187588	Harness, Ignitor
3191111	Sides
3191113	Front & Back